

# STRUCTURAL DESIGN OF *mortarless* MASONRY to IS 456:2000

## DESIGN MANUAL - Part 2a

Warwick Colefax BE(Hons) DipTechEng(Struct) MIEAust CPEng RPEQ

# 200 mortarless (design tables) UNCHAMFERED

In this mortarless masonry Design Manual Part 2a, design tables are provided for combinations of block grades (unconfined compressive strengths) and core fill grout strengths (28 day cube strengths) as follows:

**BLOCK GRADES:** 15 & 20 MPa  
**CORE FILL CONCRETE (GROUT):** M20 & M25

## AVAILABILITY of SUPPLY:

The 200 *mortarless* masonry units to which these design tables apply are available in the following regions:

Australia (NSW, QLD & VIC) (known in Australia as Pronto Block)  
Middle East (Oman, UAE)  
Asia (India)

Prior to specifying 200 *mortarless* check proximity of nearest supplier with local Licensee.

## DISCLAIMER:

This *mortarless* masonry Design Manual has been compiled to assist structural engineers quickly and efficiently prepare designs and details of load-bearing *mortarless* masonry structures and elements. Numerous design aids are provided and these cover a broad range of typical design applications. While every care has been taken to ensure the information provided is accurate and complete for the design situations and actions covered, the information should only be used by experienced practising structural engineers, and all engineers should familiarise themselves with the full contents of the applicable Standards to ensure no requirement is overlooked. Mortarless Pty Ltd, its licensees and the author accept no liability whatsoever arising out of the use or misuse of the information provided in this design manual.

## Contents:

### ► **SECTION 1. 200 mortarless MASONRY UNITS**

Cross section dimensions and properties

### ► **SECTION 2. DESIGN OF WALLS FOR AXIAL COMPRESSION**

#### Design Procedure

Calculation of effective eccentricity

**Table W1-200U:** Design axial strength of walls with 15MPa blocks & M20 grout  
Effective height factor = 0.75

**Table W2-200U:** Design axial strength of walls with 20MPa blocks & M25 grout  
Effective height factor = 0.75

**Table W3-200U:** Design axial strength of walls with 15MPa blocks & M20 grout  
Effective height factor = 1.0

**Table W4-200U:** Design axial strength of walls with 20MPa blocks & M25 grout  
Effective height factor = 1.0

### ► **SECTION 3. DESIGN OF WALLS FOR BENDING**

Reinforcing bar positions

#### Design Procedure

**Table 3.1:** Bending moment capacities (vertical and horizontal)

**Table 3.2:** Bending moment capacities of *mortarless* beams

### ► **SECTION 4. DESIGN OF WALLS FOR COMBINED BENDING AND COMPRESSION**

#### Design Procedure

**Diagram 4-1:** Interaction Diagram -  $f_{ck} = 20\text{MPa}$

**Diagram 4-2:** Interaction Diagram -  $f_{ck} = 25\text{MPa}$

### ► **SECTION 5. DESIGN OF WALLS FOR SHEAR**

#### Design Procedure

**Diagram 5-1:** Contribution of concrete to in-plane shear capacity of shear walls

**Diagram 5-2:** Contribution of reinforcement to in-plane shear capacity of shear walls

**Table 5.1:** Shear capacity of 200 *mortarless* beams without shear reinforcement

**Table 5.2:** Shear capacity of 200 *mortarless* beams with shear reinforcement